

For sterilization of Matrix products

Perform the following steps inside a Biological safety cabinet

*For tubes, sheets and custom shapes, perform the steps below in a sterile dish or tube

* Well plates are sterilized via UV, no further sterilization is needed.

1. Coat the matrix in 70% EtOH for 3-4 hours.
2. Pour off the EtOH.
3. Wash 3 times in 1X PBS.